




■ WÖHR Bikesafe 885/16 (128 parking places), handlebar width 76 cm




Note: if possible, provide an access door in the shaft area.



Section parking level



Section entrance level




■ WÖHR Bikesafe 885/16 (128 parking places), handlebar width 83 cm




Note: if possible, provide an access door in the shaft area.



Section parking level



Section entrance level




■ WÖHR Bikesafe 885/20 (160 parking places), handlebar width 76 cm




Note: if possible, provide an access door in the shaft area.



Section parking level



Section entrance level




■ WÖHR Bikesafe 885/20 (160 parking places), handlebar width 83 cm




Note: if possible, provide an access door in the shaft area.


Section parking level



Section entrance level



■ WÖHR Bikesafe 885/24 (192 parking places), handlebar width 76 cm



Note: if possible, provide an access door in the shaft area.

